

# Blackmagic Camera Setup 6.5.1



## About Blackmagic Camera Utility

### Welcome to the Blackmagic Camera Setup!

This software package allows you to update your Blackmagic Camera to the latest software release for new features, bug fixes and other enhancements.

The software installer no longer installs the Desktop Video or UltraScope applications and they will need to be downloaded separately from the Blackmagic Design website: <https://www.blackmagicdesign.com/support>

To use UltraScope via Thunderbolt with Blackmagic Cinema Camera or Production Camera 4K, download and install the Blackmagic UltraScope software. If you want to use Media Express with the supported cameras, download and install the Blackmagic Desktop Video software.

Please ensure that your device is plugged into mains power before running the software update. To update Blackmagic Camera Fiber Converter you will need to ensure that the unit is powered from the camera using the URSA 12V power supply rather than SMPTE fiber during the update.

For updating URSA Mini, URSA Broadcast and Pocket Cinema Camera 4K from Camera 4.0 or above it is advisable to export your presets and LUTs onto a card as they will be removed during this update.

### What's new in Blackmagic Camera Setup 6.5.1

#### New features for URSA Mini Pro G2

- Improved compatibility for embedded audio on SDI outputs.

**No new features in 6.5.1 for other camera models.**

### Minimum system requirements for Mac OS

- macOS 10.14 Mojave or later
- macOS 10.13 High Sierra or later
- A suitable USB 2.0 port
- Thunderbolt port for UltraScope and Media Express when using Blackmagic Cinema Camera or Blackmagic Production Camera 4K

### Minimum system requirements for Windows

- Microsoft Windows 10 64-bit
- A suitable USB 2.0 port
- A suitable Thunderbolt port when using Blackmagic Cinema Camera or Blackmagic Production Camera 4K

### Installing Blackmagic Camera Utility

Before installing the software on Windows, we recommend that you run "Uninstall Blackmagic Camera Setup" first.

While installing Camera Update on URSA Mini and URSA Mini Pro you may notice a pause around the 10% mark in the install process, this is normal and will continue installing after around 20 seconds.

While installing Camera Update on Pocket Cinema Camera 4K you may notice a pause around the 70% mark in the install process, this is normal. Please do not power off the camera as it may still be in the middle of the update process. When the update is completed, the camera will restart into its normal operating state.

After loading the software on the Blackmagic Cinema Camera PL, EF or MFT, you may notice a slight flickering on the built-in LCD screen. This is normal and expected behavior. The flickering will go away after a few minutes of operation.

## The Blackmagic Camera Installer package installs:

- Blackmagic Camera Setup
- Blackmagic RAW Player
- Blackmagic RAW Speed Test
- Uninstall Blackmagic Camera Setup
- User Manuals

## Additional Information

Some applications may use third party code under license. For details please refer to the included "Third Party Licenses.rtf" document.

*© 2019 Blackmagic Design Pty. Ltd. All rights reserved. Blackmagic Design, Blackmagic, DeckLink, Multibridge, HDLink, Videohub, and "Leading the creative video revolution" are trademarks of Blackmagic Design Pty. Ltd., registered in the U.S.A and other countries.*

Updated August 23, 2019.